

Fitting Instructions – ALKBATH25

BATHROOM LOCK

Date Modified: 12/07/2022

Last modified by: Alice W

For best results when fixing an ALKBATH follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

- 1) Separate out all components supplied as follows:
 - X1 Dust Box
 - X1 Face Plate
 - X1 Strike Plate
 - X1 Bathroom Lock
- 2) First, mark out the desired position for the lock on the door.
- 3) Next, drill/router for the lock body (Allow for face plate).
- 4) Then, drill the spindle for the lever and drill the spindle for the WC turn.
- 5) Mark out for your strike plate.
- 6) Drill for your strike plate and box keep.
- 7) Insert box keep and face plate with screws provided.
- 8) Check lock alignment with strike plate.