

Millhouse Brass Fitting Instructions – Mortice Knobs

Millhouse Brass – Mortice Knobs

Date Modified: 13/12/2021

Last modified by: Sophie Wells

For best results when fixing Millhouse Brass Mortice Knobs, follow these instructions.

Atlantic recommend this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

- 1) Separate out all components supplied as following:
 - 2xKnobs including a grub screw each
 - 2xBackplates (located on back of knob)
 - 1xAllen Key
 - Pack of 8 screws
 - 1xSpindle
 - 2x plastic fitting guide disks (assembled inside backplate – screw off backplate to locate plastic fitting guide disks)
- 2) Release grub screw from knob prior to fixing and keep in a safe place
- 3) Install your chosen latch into the door. For best results use the Atlantic 4" Latch (AL4)
- 4) Insert the spindle provided through the pre-drilled holes in the door, ensuring the gouged cut out at each end of the spindle is facing down.
- 5) Fit the plastic fitting guide disks into the backplate aperture.
- 6) Locate the backplates over the spindle through the plastic fitting guide disk.
- 7) Ensuring spindle is horizontal, screw backplate to door.
- 8) Repeat procedure on the other side of the door.
- 9) Once this stage is complete, insert knob onto spindle, ensuring the grub screw is facing down.
- 10) Thread knob onto backplate turning clockwise until knob plate butts the door.
- 11) With Allen key provided, secure grub screw to spindle.
- 12) Repeat procedure on the other side of the door, and test knob action.