

Old English Fitting Instructions – Lever on Back Plate

Old English – Lever on Backplate

Date Modified: 04/05/2022

Last modified by: Alice W

For best results when fixing Old English levers, follow these instructions.

1) Separate out all components supplied as follows:

X1 pair of levers on backplate
X1 spindle
X8 screws
X1 Allen Key

2) Once the chosen lock is fitted, insert the spindle through the spindle hole in the lock with the cut-out groove of the spindle facing down. You **must** ensure that it is central in the latch, with the same length of the spindle on either side of the door.

Expert Tip - At this point, with a permanent marker, mark a line on the spindle on both sides of the door, so that at a later stage, you can ensure it remains central.

- 3) Next, remove the spindle and insert it into one of the levers on backplate. Ensuring the line marked on the spindle is flush with the rear of the backplate.
- 4) Using the Allen Key, tighten the grub screw locking the handle onto the spindle.
- 5) Now, insert this lever on backplate into the pre-fitted lock on the door (ensure the backplate is lined up, parallel to the door's edge).
- 6) With screws provided, screw the backplate to the door.
- 7) Repeat this with the other lever on backplate, using the remaining screws provided.
- 8) Tighten up the main grub screw using the Allen Key.