

Old English Fitting Instructions – Mortice Knobs

Old English – Mortice Knobs

Date Modified: 13/03/2022

Last modified by: Alice W

For best results when fixing Old English Mortice Knobs (OE50, OE58) follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

- 1) Separate out all components supplied as following:
 - 2xKnobs including a grub screw each
 - 2xBackplates (located on back of knob)
 - 1xAllen Key
 - Pack of 8 screws
 - 1xSpindle
 - 2x plastic fitting guide disks (assembled inside backplate – screw off backplate to locate plastic fitting guide disks)
- 2) Release grub screw from knob prior to fixing and keep in a safe place
- 3) Install your chosen latch into the door. For best results use the Atlantic 4" Latch (AL4)
- 4) Insert the spindle provided through the pre-drilled holes in the door, centralize the spindle in the door and mark the spindle to indicate the edge of the door. Ensure the gouged cut out at each end of the spindle is facing down.
- 5) Remove the fixing plate from the rose.
- 6) Fit the plastic fitting guide disks into the backplate aperture.
- 7) Locate the backplates over the spindle through the plastic fitting guide disk.
- 8) Ensuring spindle is horizontal, screw backplate to door with screws provided.
- 9) Repeat the procedure on the other side of the door.
- 10) Remove the spindle from the door and insert it into one of the knobs ensuring that the grub screw is facing down.
- 11) Insert the spindle into the latch in the door and thread the knob onto the backplate until it butts the door.
- 12) With the Allen key provided, secure the grub screw to the spindle.
- 13) Repeat the procedure on the other side of the door, and the test knob action operates freely.
- 14) If the knob movement is not as required, remove one of the knobs and adjust fixing plate to ensure all is aligned.