

Old English Fitting Instructions – Mortice Knobs

Old English – Mortice Knobs – OE57, OE59 & OE60

Date Modified: 11/07/2024

Last modified by: Brock Hutchins

For best results when fixing Old English Mortice Knobs (OE60) follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

- 1) Separate out all components supplied as following:
 - 2x Knobs including a grub screw each
 - 2x Roses – Not fixed to the knob
 - 1x Allen Key
 - Pack of 8 screws
 - 1x Threaded spindle
- 2) Release grub screw from the knob and unwind the spindle all the way.
- 3) Install your chosen latch into the door. For best results use the Atlantic 3 or 4" Latch (AL3/AL4)
- 4) Install the latch as referenced on the associated fitting instructions
- 5) Screw in the spindle to one of the knobs, ensuring one of the flats of the spindle is at 90 degrees to the grub screw hole.
- 6) With the grub screw pointing down to the floor, place the rose over the neck of the knob and insert the spindle into the follower on the latch.
- 7) Place the rose around the neck of the other side of the opposing knob, and then screw it onto the spindle that is protruding through the door.
- 8) Once this is done, align the knobs so that they both sit level and square to the front of the door, and each other, and once this is done, ensuring that the grub screws on both knobs are pointing at the ground, put in the grub screws and tighten up.
- 9) With this done, take 4 of the supplied screws on each side and fix the rose in place, orienting the screws on this to your choice.
- 10) Test for function and adjust as needed. If they are binding up, this may be that the knobs are sitting square to one another. To adjust this, you may need to repeat step 9.