

Fitting Instructions – Status WC Turn and release on round rose

S2WCR(finish)

Date Modified: 10/08/2022

Last modified by: Brock H

For best results when fixing a Deadlock follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

X1 WC turn

X1 Release

X1 5mm spindle

2x Bolt through fixings

6x Screws

- 1) First, mark out the desired position for the turn and release on the door.
- 2) Next, mark out and drill the aperture for the spindle, taking the backset from the deadbolt you have selected, sold separately.
- 3) Place the spindle in the deadbolt installed in the door, and place the turn and release on the spindle, having removed the outer rose from the turn and release.
- 4) Push the turn and release tight up to the door, and mark out for the bolt through fixings.
- 5) Remove turn and release and drill for the bolt through fixings with an appropriately size drill bit.
- 6) Place the bolt through fixings on the release and fix the bolt through fixings onto the release and fasten, leaving a little slack.
- 7) Place release side onto the spindle and bolt through fixings in the appropriate holes
- 8) Push tight to the door and fasten using 3no screws provided.
- 9) Place turn side onto the door and fasten onto the door using the bolt through fixings and 3no screws provided.
- 10) Test to ensure the turn and release works correctly.