



Kolorbond uPVC Painting Kits

Kolorbond uPVC Painting Kits are designed around [Kolorbond Aquatek](#) paint and contain all of the products and application tools required to ensure a high quality finish on uPVC windows and doors.

Kolorbond Aquatek is a water based paint with excellent adhesion to many substrates including uPVC. It contains virtually no VOCs and therefore has a minimal effect on the environment.

Available in 4 pack sizes:

Pack A - (Expected to cover up to an approximate total surface area of 5m²)

- This should cover, externally, 3 medium size window frames each with 2 openers
- If you also want to paint one side of a door it will take about the same amount of paint as 1 medium size window frame
- Pack A should be sufficient for the front external window frames of an average terraced house

Pack A Contents:

- 1L [Kolorbond Aquatek](#)
- 250ml [Technispray Vinylkleen](#)
- 250ml [Technispray Windowprep](#)
- 2 x Red abrasive pads
- 2 x Lint free cloths (1 for applying Vinylkleen and 1 for applying Windowprep)
- 1 x Good quality synthetic 1.5 inch paint brush

Pack B - (Expected to cover up to an approximate total surface area of 10m²)

- This should cover, externally, 6 medium size window frames each with 2 openers
- If you also want to paint one side of a door it will take about the same amount of paint as 1 medium size window frame
- Pack B should be sufficient for the front external window frames of an average terraced house

Pack B Contents:

- 2L Kolorbond Aquatek
- 1L Technispray Vinylkleen
- 1L Technispray Windowprep
- 2 x Red abrasive pads
- 2 x Lint free cloths (1 for applying Vinylkleen and 1 for applying Windowprep)
- 1 x Good quality synthetic 1.5 inch paint brush

Pack C - (Expected to cover up to an approximate total surface area of 15m²)

- This should cover, externally, the windows and doors of an average semi-detached house

Pack C Contents:

- 3L Kolorbond Aquatek
- 1L Technispray Vinylkleen
- 1L Technispray Windowprep
- 2 x Red abrasive pads
- 2 x Lint free cloths (1 for applying Vinylkleen and 1 for applying Windowprep)
- 1 x Good quality synthetic 1.5 inch paint brush

Pack D - (Expected to cover up to an approximate total surface area of 25m²)

- This should cover, externally, the windows and doors of an average detached house, or the external window frames, doors and fascia, guttering etc. of a terraced house

Pack D Contents:

- 5L Kolorbond Aquatek
- 1L Technispray Vinylkleen
- 1L Technispray Windowprep
- 4 x Red abrasive pads
- 4 x Lint free cloths (2 for applying Vinylkleen and 2 for applying Windowprep)
- 1 x Good quality synthetic 1.5 inch paint brush

PPE requirements (not included in packs):

- Good ventilation
- Eye/face protection - Wear chemical splash goggles
- Hand protection - Wear protective gloves made of the following material
- Neoprene
- Nitrile rubber
- Rubber (natural, latex)

Refer to each product Material Safety Data Sheet for full details.

Painting with Kolorbond Aquatek

If you are brush applying Kolorbond Aquatek you will require disposable gloves and possibly protective clothing. A face mask is not necessary but essential if you decide to spray apply (the mask will require a particulate filter). To reduce the chance of over painting it is a good idea to apply a layer of masking tape on glass and other adjoining substrates.

Before starting to clean the surfaces to be painted, dilute the Vinylkleen, one part to three parts water.

Thoroughly clean the surface using the diluted Vinylkleen on one of the cloths provided. Keep turning the cloth as it becomes dirty.

Now lightly rub over all surfaces to be painted with the red abrasive pad. This will dull the surface but should not leave any scratch marks. If you are painting over wood grain foil, be careful not to rub too hard which can damage the wood grain finish.

Now thoroughly clean again using a second cloth with Windowprep on it. This will remove any remaining contaminants and any dust produced earlier. Again, turn the cloth as it becomes dirty. Windowprep contains alcohols so please wear gloves to protect your skin from drying.

When everything is dry you are ready to start painting. Firstly, stir the paint making sure that you stir right to the bottom of the can so that any settled colourants are fully mixed back in. Do not stir too vigorously as you do not want to create bubbles in the paint.

Apply the paint using the brush provided of a good quality synthetic brush. Kolorbond Aquatek dries too quickly to be roller applied. If you want to do this you will have to add a quantity of [Kolorbond Kolorflow](#) (not supplied) to the paint.

Brush on the paint in a nice even coat. Do not apply too much paint and then try to 'work' it. This paint dries too quickly, and you can damage the finish.

When the paint is dry, after about 15 minutes, apply a second even coat being careful not to leave deep brush marks.

If you have a break during painting, make sure that you put your brush into water straight away. Should you allow the paint to dry on the brush you will have to throw the brush away. You will not get the dried paint off.

Although Kolorbond Aquatek dries very quickly it takes up to a week to fully cure so please treat it gently for the first few days. If you have an area you want to cure quickly you can apply hot air from a domestic hairdryer once the paint is totally dry. Do not, of course, get the paint too hot or you could damage it.

On finishing painting, immediately wash out your brush and any other equipment with plenty of water.

NB. When prepping and painting, as described above, you should always use the correct protective equipment to protect your eyes, skin, respiratory tract and clothes etc. i.e. protective gloves, eye protection, clothing covering, and respiratory masks fitted with organic vapour filters.

Always ensure that your working area is sufficiently ventilated.

Please read technical and safety data sheets before commencing.