

LIGHTHOUSE®

USER MANUAL L/H EMINI200R LED SLIMLINE TORCH

BEFORE USING FOR THE FIRST TIME

Please ensure you read and understand these instructions clearly before using this product for the first time. Failure to do so could result in personal injury or damage to the product. It is important you retain this user manual for future reference.

SAFETY PRECAUTIONS

- ▶ Do not use the torch in the immediate vicinity of inflammable materials or gases.
- ▶ Make sure that the torch lens is not covered during use.
- ▶ Only use the accessories included with this product when charging the torch.
- ▶ Keep the torch out of reach of children and pets.
- ▶ Do not point the torch directly in your own, any other person's or animals eyes.
- ▶ Always check the mains cable before using the charger. If the cable or any part of the charger is damaged, replace with a like for like spare.

TECHNICAL DATA

BATTERY TYPE	3.7V Lithium-ion 500mAh Rechargeable
LED TYPE	COB LED
BRIGHTNESS	200 Lumens
BEAM DISTANCE	20 Metres
RUN TIME	2 Hours
CHARGE TIME	1.5 Hours (Approx.)
IMPACT RESISTANT	Up to 1 Metre
WATER RESISTANT	IP44
WEIGHT / SIZE	37g / 123 x 25 x 12mm
SUPPLIED WITH	300mm USB-C Charging Lead

MAINTENANCE

There are no serviceable parts inside this torch. Opening, or visible attempts to repair the torch will void any guarantee. LED bulbs should not wear out under normal conditions and do not need to be replaced.

CLEANING

Use a soft cloth or cotton swab with water or medical alcohol to clean the lens. Care should be taken during cleaning. Allow the torch to completely dry before using. Do not use any harsh chemicals or abrasive materials when cleaning, as this may damage the torch.

DISPOSAL OF THIS PRODUCT

If at some point you intend to dispose of this product, please keep in mind that many of its components consist of valuable materials which can be recycled. Please do not dispose of this product in the household waste bin, check instead with your local council for recycling facilities in your area.

Do not dispose of used batteries in the household waste, or expose to fire. Lighthouse hold no responsibility for personal injury or damage caused by incorrectly disposing of batteries.

The plastic in this product may contain chemicals known by the state of California to cause cancer and birth defects or other reproductive harm.

OPERATING FUNCTIONS

The output functions are controlled by a sequential switch on the front of the light:

- ▶ Press and release the on/off button to turn on the main white light.
- ▶ Press and release again to change to the red strobe light.
- ▶ Alternatively press and hold the on/off button for two seconds to turn on the red light, skipping the white light stage.

This torch also features a dimmable function, with the white light turned on press and hold the on/off button down to increase or decrease the light output brightness. The light will flash to indicate when it has reached the highest or lowest output level. Release the on/off button when the desired light output level is reached.

RECHARGING

- ▶ Ensure the battery is fully charged before using the torch for the first time. This should be a minimum of 2 hours.
- ▶ It is important for the torch to be charged every three months to maintain the optimum condition of the battery.
- ▶ While on charge, the indicator lamp will glow red and will turn blue when the battery is fully charged.

The charging cable included with this product is for recharging the battery only. It cannot be used to directly power the torch.

USING THE CHARGING LEAD

Plug the USB charger lead into the micro USB charging socket on the side of the torch. Plug the other end of the lead into any suitable USB charging outlet.

PLEASE NOTE THE FOLLOWING

For the best performance results, Lithium-Ion batteries should not be stored for prolonged periods of time without being charged at regular intervals. Self discharge rate is approximately 10% per month. It is recommended the torch is stored in a higher charged state, in a cool, dry environment, away from direct sunlight.

It is important to note that when charging the torch, it should not be used and should be kept away from children and pets.

GUARANTEE

Rechargeable battery life depends on many factors and the cells can become easily damaged, dependent on environmental and storage conditions. Your product is guaranteed from defect for a period of **1 year**, this excludes the battery which is covered for 90 days from the date of purchase, if you notice the running or charge times decreasing this is normal over the lifetime of the battery and is classed as fair wear and tear.

There will be some items within our range which will be non-serviceable but, in most cases we can supply replacement batteries for our products.

LIGHTHOUSE TORCHES
Long Reach, Galleon Boulevard, Crossways Business Park, Dartford, Kent, DA2 6QE, UK

QFF DISTRIBUTION
24 Magna Drive, Magna Business Park, Citywest Road, Dublin 24, D24 FNYO, Ireland.

 www.lighthouse-torches.com

