

Expert finishes for wood and metal

Rustins Ltd, Waterloo Road, London NW2 7TX. Tel: +44 (0)20 8450 4666 www.rustins.co.uk

June 2017

PRODUCT DATA SHEET

,
Acrylic Wood Filler (AWOO)
An acrylic based, ready to use multi-purpose filler, designed for general and minor repairs for all types of interior and exterior timber. Available in Natural, Mahogany, Teak, Oak and White.
To fill nail holes, dents and cracks in wood. For interior and exterior use.
Does not crack. Quick drying and easily sanded. Maybe dyed, varnished or painted.
Before applying ensure that area to be filled is sanded smooth, clean, dry and free from wax and dust.
Apply using a putty knife, forcing into the cracks and holes. Leave slightly proud of the surface to allow for possible shrinkage and to enable sanding. Allow to dry for 2 hours under good conditions. Never exceed layers of 3 mm when applying or shorten the drying time. If it is cold or damp it may require longer to dry. If the hole to be filled is deep, it should be filled in layers of 3 mm allowing each to dry before further layers are applied.
N/A
2 hours depending on the temperature and humidity. Do not use below 10°C or in high humidity.
Leave to dry for 2-3 hours before applying undercoat or varnish. Deep filled area may require longer.
Ideally 15-25°C.
N/A
N/A
Can be used under all Rustins paints and varnishes. Most other brands should be compatible but if in doubt carry out a small test. Always test first on an inconspicuous area to check that the colour is correct. The Wood Filler may accept dyes and stains differently to the surrounding wood.
Stir well if there is any sign of separation.
A very long time if stored in original sealed container in a cool dry place. Do not store below 5°C.
Keep out of reach of children. Wash hands after use. A Safety Data Sheet is available upon request or on www.rustins.co.uk /resource-centre
Clean all equipment immediately after use with warm water.
250ml